



FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-001	94430-4A000	HYUNDAI	 <p>WSENSOR</p>
8-2-10-002	94430-43011	HYUNDAI GRACE	 <p>WSENSOR 3 PIN</p>
8-2-10-003	94430-43020	HYUNDAI	 <p>WSENSOR 3 PIN</p>
8-2-10-004	94430-4B000	HYUNDAI	 <p>WSENSOR</p>
8-2-10-005	94430-44620	HYUNDAI	 <p>WSENSOR 3 PIN</p>

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-006	94460-22020	HYUNDAI 98/99 DAEWOO	 <p>W/SENSOR</p>
8-2-10-007	94460-22040	HYUNDAI DAEWOO	 <p>W/SENSOR</p>
8-2-10-008	94460-25000	HYUNDAI DAEWOO	
8-2-10-009		HYUNDAI	 <p>2 PIN</p>
8-2-10-010		HYUNDAI	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-011	94460-220200D	HYUNDAI 98/99 DAEWOO	
8-2-10-012	9608514		
8-2-10-013	0S093 60 960B	KIA BESTA	
8-2-10-014	KK 142 60 960A KK 142 60 960B	KIA	
8-2-10-015	OK 240 60 960A	KIA	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-016		KIA	<p>W/SENSOR</p> 
8-2-10-017	OK 758 60 960D	KIA	<p>W/SENSOR</p> 
8-2-10-018	OK 72C 60 960	KIA	<p>W/SENSOR</p> 
8-2-10-019	KKY01E-60-960 KK 143-60-960	KIA FORD	
8-2-10-020	KKY01-60-960	KIA FORD	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-021	83320-29026	TOYOTA	
8-2-10-022	83320-80060 89920-29375	TOYOTA	
8-2-10-023	83320-60051	TOYOTA	
8-2-10-024	83320-29345 83320-29785	TOYOTA	
8-2-10-025	83320-87500	TOYOTA	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-026	83320-95189 83320-80043	TOYOTA	
8-2-10-027	83320-80165 83320-27240	TOYOTA	
8-2-10-028	83320-89110 83320-80118	TOYOTA	
8-2-10-029	83320-80365 83320-38021	TOYOTA	
8-2-10-030	83320-38011	TOYOTA	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-031	83320-69025/820G1	TOYOTA	
8-2-10-032	83320-69015	TOYOTA	
8-2-10-033	83320-39176	TOYOTA	
8-2-10-034	83320-80115 83320-80106	TOYOTA	
8-2-10-035	83320-39405 83320-35120 83320-35130	TOYOTA	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-036	83320-29428	TOYOTA	
8-2-10-037	83320-60050	TOYOTA	
8-2-10-038	83320-39415	TOYOTA	
8-2-10-039	83320-89801	TOYOTA	
8-2-10-040	83320-39185 83320-39186	TOYOTA	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-041	83320-39555	TOYOTA	
8-2-10-042	83320-39565	TOYOTA	
8-2-10-043	83320-29016	TOYOTA	
8-2-10-044	83320-39405 83320-35120 83320-35130 83320-89110-A1	TOYOTA	
8-2-10-045	83320-19125	TOYOTA	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-046	83320-19205	TOYOTA	
8-2-10-047	83320-29255	TOYOTA	
8-2-10-048	83320-29125	TOYOTA	
8-2-10-049	83320-59016	TOYOTA	
8-2-10-050	83320-39205	TOYOTA	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-051	83320-19398	TOYOTA	
8-2-10-052	83320-39125	TOYOTA	
8-2-10-053	83320-39187 83320-89106	TOYOTA	
8-2-10-054	83320-80204	TOYOTA	
8-2-10-055	83320-33030	TOYOTA	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-056	83320-49075	TOYOTA	
8-2-10-057	83320-80195	TOYOTA	
8-2-10-058	83320-12512	TOYOTA	
8-2-10-059	83320-16290	TOYOTA	
8-2-10-060	83320-80183	TOYOTA	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-061	83320-12640	TOYOTA	
8-2-10-062	83320-52070	TOYOTA	
8-2-10-063	83320-80342	TOYOTA	
8-2-10-064	83320-19875 83320-19706	TOYOTA	<p>WSENSOR</p> 
8-2-10-065	83320-19387 83320-19398	TOYOTA	<p>WSENSOR</p> 






FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-066	89421-62611	TOYOTA	
8-2-10-067	83320-80012	TOYOTA	
8-2-10-068	83320-80105 83320-80129	TOYOTA	
8-2-10-069	83320-80082 4P	TOYOTA	
8-2-10-070	83320-80080 83320-80074	TOYOTA	






FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-071		TOYOTA	
8-2-10-072	83320-69035	TOYOTA	
8-2-10-073	83320-80153	TOYOTA	
8-2-10-074	83320-80367 83320-8039	TOYOTA	
8-2-10-075	83320-80358 ZJ157-35520	TOYOTA	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-076	83320-OK040	TOYOTA VIGO 4WD	
8-2-10-077	77501-87605	DAIHATSU	
8-2-10-078	77501-87606	DAIHATSU	
8-2-10-079	83320-87515	DAIHATSU	
8-2-10-080	83320-87501 071700-2133	DAIHATSU	






FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-081	83320-87510	DAIHATSU	
8-2-10-082	83320-87515	DAIHATSU	
8-2-10-083	16676.12298	DAIHATSU	
8-2-10-084	77501-87307 071700-2383	DAIHATSU	
8-2-10-085	77501-87601 77501-35120	DAIHATSU	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-086	83320-87513-001	DAIHATSU	
8-2-10-087	83320-87514-001	DAIHATSU	
8-2-10-088	77601-87315	DAIHATSU	
8-2-10-089	77501-87704-001	DAIHATSU	
8-2-10-090	77501-87780	DAIHATSU	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-091		DAIHATSU	
8-2-10-092	071700-7074 071700-7053	DAIHATSU	
8-2-10-093	37800-SB4-013 37800-SA0-013	HONDA	
8-2-10-094	37800-SA5-306	HONDA	
8-2-10-095	37800-SB4-013 37800-SA0-013	HONDA	






FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-096	37800-SH4-004	HONDA	
8-2-10-097	Mb697191	MITSUBISHI	
8-2-10-098	MC-845822	MITSUBISHI	
8-2-10-099	MB 434244	MITSUBISHI	W/SENSOR 
8-2-10-100	37800-SB4-013 37800-SA0-013	MITSUBISHI	






FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-101	MC 849785	MITSUBISHI	
8-2-10-102	MB 114900	MITSUBISHI	
8-2-10-103	MB 314923	MITSUBISHI	
8-2-10-104	MB 056224 MB 056228	MITSUBISHI	
8-2-10-105	MB 314923	MITSUBISHI	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-106	MB 125136	MITSUBISHI	
8-2-10-107	MB 415680	MITSUBISHI	
8-2-10-108	MB 302651	MITSUBISHI	
8-2-10-109	TK 322826	MITSUBISHI	
8-2-10-110	MB 141179	MITSUBISHI	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-111	MB 141180	mitsubishi	
8-2-10-112	MB 031525	mitsubishi	
8-2-10-113	MB 070551	mitsubishi	
8-2-10-114	TK 031610	mitsubishi	
8-2-10-115	MB 070150	mitsubishi	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-116	MB 302650 MB 302651	MITSUBISHI	
8-2-10-117	MB 337945	MITSUBISHI	
8-2-10-118	MB 330760	MITSUBISHI	
8-2-10-119	CW 609967	MITSUBISHI	
8-2-10-120	CW 609968	MITSUBISHI	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-121	CW 603350	MITSUBISHI	
8-2-10-122	MB 434245 MB 434250	MITSUBISHI	
8-2-10-123	MB 434268 MB 509082	MITSUBISHI	
8-2-10-124	MR 158205 MB 434245	MITSUBISHI	
8-2-10-125	CW 608428	MITSUBISHI	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-126	CW 608429	MITSUBISHI	
8-2-10-127	MB 818634-Z41	MITSUBISHI	
8-2-10-128	MR 135469	MITSUBISHI	
8-2-10-129	MB 852966	MITSUBISHI	
8-2-10-130	MR 135338 MR 135339	MITSUBISHI	






FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-131	MB 571603	mitsubishi	 <p>WSENSOR</p>
8-2-10-132	MB 487703	mitsubishi	 <p>WSENSOR</p>
8-2-10-133	PW 510628	mitsubishi	 <p>WSENSOR 3 PIN</p>
8-2-10-134	PW 510680	mitsubishi	 <p>WSENSOR 3 PIN</p>
8-2-10-135	MB 114009	mitsubishi	 <p>WSENSOR</p>

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-136	MR 503462	MITSUBISHI	
8-2-10-137	MC 844110	MITSUBISHI	
8-2-10-138	MC 844113	MITSUBISHI	
8-2-10-139	MC 850100	MITSUBISHI	
8-2-10-140	MB 084255	MITSUBISHI	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-141	MC 342551 271700-3150	MITSUBISHI	
8-2-10-142	MC 896134 MK 322827 MB 853352	MITSUBISHI	
8-2-10-143	MR 487624 MB 285834	MITSUBISHI	WSENSOR 
8-2-10-144	MB 509082	MITSUBISHI	WSENSOR 
8-2-10-145	MB 122790	MITSUBISHI	






FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-146	MR 122795	MITSUBISHI	
8-2-10-147	34810-79001	SUZUKI FORD	
8-2-10-148	34810-79002 34810-72010	SUZUKI FORD	
8-2-10-149	34810-79010 34810-77310	SUZUKI	
8-2-10-150	34810-85000	SUZUKI FORD	





FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-151	34810-60A11	SUZUKI	
8-2-10-152	34810-60A01	SUZUKI	
8-2-10-153	34810-77E00	SUZUKI	
8-2-10-154	34810-80001	SUZUKI	
8-2-10-155	34810-71000	SUZUKI	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-156		SUZUKI	
8-2-10-157	8-94222-974-2	ISUZU	
8-2-10-158	8-94341-682-0	ISUZU	
8-2-10-159	8-94318-397-0	ISUZU	
8-2-10-160	8-94318-398-0	ISUZU	<p>W/SENSOR</p> 

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-161	38999 011 8001	SUZUKI	
8-2-10-162	37777 049 1201	ISUZU	
8-2-10-163	5-83141-033-0	ISUZU	
8-2-10-164	5-83141-016-0	ISUZU	
8-2-10-165	5-83141-018-0	ISUZU	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-166	5-83141-004-1	SUZUKI	
8-2-10-167	5-83141-012-0	ISUZU	
8-2-10-168	8-94407-427-2	ISUZU	
8-2-10-169	8-94457-778-0	ISUZU	
8-2-10-170	8-94156-896-0 8-94457-780-0	ISUZU	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-171	8-94310-690-1	SUZUKI	
8-2-10-172	8-97966-377-0	ISUZU	
8-2-10-173	8-94316-190-0 8-94316-196-0 8-94316-188-0	ISUZU	
8-2-10-174	1-83141-037-0	ISUZU	
8-2-10-175	8-97137-807-0	ISUZU	



FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-176		ISUZU	
8-2-10-177	25060-H5000	NISSAN SUNNY	
8-2-10-178	25060-B9560/01W10 25060-B9500/01W00	NISSAN	
8-2-10-179	25060-H8500/M9201	NISSAN SUNNY	
8-2-10-180	25060-B5000	NISSAN	






FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-181	25060-18G25	NISSAN	 <p>W/SENSOR</p>
8-2-10-182	25060-15G01 25060-15G25	NISSAN	 <p>W/SENSOR</p>
8-2-10-183	25060-24G26	NISSAN	 <p>W/SENSOR</p>
8-2-10-184	25060-P4400	NISSAN	 <p>W/SENSOR</p>
8-2-10-185	25060-H9400	NISSAN	 <p>2 PIN</p>

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-186	25060-T3600	NISSAN	2 PIN 
8-2-10-187	25060-U1500 25060-K2900 25060-46500	NISSAN	
8-2-10-188	25060-G2501	NISSAN	2 PIN 
8-2-10-189	25060-G1000	NISSAN	1 PIN 
8-2-10-190	25060-G0302	NISSAN	






FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-191	25060-H6600	NISSAN	
8-2-10-192	25060-T8900	NISSAN	
8-2-10-193	25060-T6001	NISSAN	
8-2-10-194	25060-J0100	NISSAN	
8-2-10-195	25060-G2502 25060-G2503	NISSAN	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-196	25060-3T200-5	NISSAN	
8-2-10-197	25060-W5000 25060-W57G0	NISSAN	
8-2-10-198	25060-W6000	NISSAN	
8-2-10-199	25060-G6000	NISSAN	
8-2-10-200	25060-T8002	NISSAN	




FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-201	25060-01W00	NISSAN	
8-2-10-202	25060-10W01	NISSAN	
8-2-10-203	25060-V0100	NISSAN	WSENSOR 
8-2-10-204	25060-H9201	NISSAN	WSENSOR 
8-2-10-205	25060-20310	NISSAN	






FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-206	25060-50Y02 25060-50Y01	NISSAN	
8-2-10-207	25060-BM199A	NISSAN	
8-2-10-208		NISSAN	
8-2-10-209	25060-14A03 25060-14A00	NISSAN	
8-2-10-210	25060-01A02	NISSAN	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-211	25060-50A00	NISSAN	
8-2-10-212	25060-51A00	NISSAN	W/SENSOR 3 PIN 
8-2-10-213	25060-C6000	NISSAN	
8-2-10-214		NISSAN	W/SENSOR 
8-2-10-215	25060-01A02	NISSAN	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-216	w023-60960B	MAZDA	
8-2-10-217	UB41-60-960	MAZDA	
8-2-10-218	UB54-60-960	MAZDA	
8-2-10-219	0778-67-170B	MAZDA	
8-2-10-220	0517-67-170 0517-60-960	MAZDA	



FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-221	3874C-308-4E	MAZDA	
8-2-10-222	3874-67-180C	MAZDA	
8-2-10-223	0317-67-170	MAZDA	
8-2-10-224	1823-67-180A	MAZDA	
8-2-10-225	0603-66-770	MAZDA	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-226	12E-1414-352	MAZDA	
8-2-10-227	W210-60-960 271700-0701	MAZDA	
8-2-10-228	HB46-60-960	MAZDA	
8-2-10-229	UB39-60-960C	MAZDA	
8-2-10-230	UH71-60-960	VDO	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-231	1222588457-468	RENAULT	
8-2-10-232	504 SALOON 5100 320 836 02 1526-74	PEUGEOT	
8-2-10-233	504 WAGON 5100 310 604 01 2091102 1074	PEUGEOT	
8-2-10-234	108-020	PEUGEOT	
8-2-10-235	20911021072	PEUGEOT 505	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-236	SA 47-60960B	FORD	
8-2-10-237	1391-60960	FORD	
8-2-10-238	S113-60-960	FORD	
8-2-10-239	KK137-60-960	FORD	
8-2-10-240	S604-60-960	FORD	






FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-241	BJ79-60-960A	FORD MAZDA	 <p>WSENSOR</p>
8-2-10-242	BF68-60-960	FORD MAZDA	
8-2-10-243	BR70-60-960	FORD MAZDA	
8-2-10-244	BS07-60-960	FORD MAZDA	 <p>WSENSOR</p> <p>FOR:FORD 90LASER 1.1</p>
8-2-10-245	G030-60-960	FORD MAZDA	 <p>WSENSOR</p>

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-246	G031-60-960	FORD MAZDA	
8-2-10-247	GIB-60-960	FORD MAZDA	WSENSOR 
8-2-10-248	GR11-60-960 G212-60-960	FORD MAZDA	
8-2-10-249	GR12-60-960	FORD MAZDA	WSENSOR 
8-2-10-250	B09058 B09059 B09060	FORD	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-251	S017-60-960	FORD MAZDA	
8-2-10-252	S002-60-960	FORD MAZDA	
8-2-10-253	B001-60-960	FORD MAZDA	<p>W/SENSOR</p> 
8-2-10-254	B001-60-960	FORD MAZDA	
8-2-10-255	S019-60-960	FORD	

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-256	34810-76A03	FORD	
8-2-10-257	88BB-9275AA 87BB-9275AB	FORD	
8-2-10-258		Turkey	
8-2-10-259	04115777 12V		
8-2-10-260	01724U91		




FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-261			
8-2-10-262			
8-2-10-263			
8-2-10-264			
8-2-10-265		TLAF 293	


FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-261			
8-2-10-262	TBS 5114/02/W	PAYKAN OTHER	
8-2-10-263	TBS 5114/03/W	PAYKAN OTHER	
8-2-10-264	TBS 5114/04/W	PAYKAN OTHER	
8-2-10-265			

FUEL LEVEL FLOAT

ISO9001:2000/TS16949

8-2-10-266			
8-2-10-267			